



# IMX415 Board-M12 for RZ/V2H Evaluation Board Kit

Hardware Manual

## Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate application examples. You are fully responsible for the incorporation or any other use of the circuits, software, and information in the design of your product or system. CSM SOLUTION disclaims any and all liability for any losses and damages incurred by you or third parties arising from the use of these circuits, software, or information.
2. CSM SOLUTION hereby expressly disclaims any warranties against and liability for infringement or any other claims involving patents, copyrights, or other intellectual property rights of third parties, by or arising from the use of CSM SOLUTION products or technical information described in this document, including but not limited to, the product data, drawings, charts, programs, algorithms, and application examples.
3. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of CSM SOLUTION or others.
4. You shall be responsible for determining what licenses are required from any third parties, and obtaining such licenses for the lawful import, export, manufacture, sales, utilization, distribution or other disposal of any products incorporating CSM SOLUTION products, if required.
5. You shall not alter, modify, copy, or reverse engineer any CSM SOLUTION product, whether in whole or in part. CSM SOLUTION disclaims any and all liability for any losses or damages incurred by you or third parties arising from such alteration, modification, copying or reverse engineering.
6. CSM SOLUTION products are not intended or authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems; surgical implantations; etc.), or may cause serious property damage (space system; undersea repeaters; nuclear power control systems; aircraft control systems; key plant systems; military equipment; etc.). CSM SOLUTION disclaims any and all liability for any damages or losses incurred by you or any third parties arising from the use of any CSM SOLUTION product that is inconsistent with any CSM SOLUTION data sheet, user's manual or other CSM SOLUTION document.
7. Notwithstanding any security measures or features that may be implemented in CSM SOLUTION hardware or software products, CSM SOLUTION shall have absolutely no liability arising out of any vulnerability or security breach, including but not limited to any unauthorized access to or use of a CSM SOLUTION product or a system that uses a CSM SOLUTION product. CSM SOLUTION DOES NOT WARRANT OR GUARANTEE THAT CSM SOLUTION PRODUCTS, OR ANY SYSTEMS CREATED USING CSM SOLUTION PRODUCTS WILL BE INVULNERABLE OR FREE FROM CORRUPTION, ATTACK, VIRUSES, INTERFERENCE, HACKING, DATA LOSS OR THEFT, OR OTHER SECURITY INTRUSION ("Vulnerability Issues"). CSM SOLUTION DISCLAIMS ANY AND ALL RESPONSIBILITY OR LIABILITY ARISING FROM OR RELATED TO ANY VULNERABILITY ISSUES. FURTHERMORE, TO THE EXTENT PERMITTED BY APPLICABLE LAW, CSM SOLUTION DISCLAIMS ANY AND ALL WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO THIS DOCUMENT AND ANY RELATED OR ACCOMPANYING SOFTWARE OR HARDWARE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.
8. When using CSM SOLUTION products, refer to the latest product information and ensure that usage conditions are within the ranges specified by CSM SOLUTION with respect to maximum ratings, operating power supply voltage range, heat dissipation characteristics, installation, etc. CSM SOLUTION disclaims any and all liability for any malfunctions, failure or accident arising out of the use of CSM SOLUTION products outside of such specified ranges.
9. Although CSM SOLUTION endeavors to improve the quality and reliability of CSM SOLUTION products, semiconductor products have specific characteristics, such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. CSM SOLUTION products are not subject to radiation resistance design. You are responsible for implementing safety measures to guard against the possibility of bodily injury, injury or damage caused by fire, and/or danger to the public in the event of a failure or malfunction of CSM SOLUTION products, such as safety design for hardware and software, including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult and impractical, you are responsible for evaluating the safety of the final products or systems manufactured by you.
10. Please contact a CSM SOLUTION sales office for details as to environmental matters such as the environmental compatibility of each CSM SOLUTION product. You are responsible for carefully and sufficiently investigating applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive, and using CSM SOLUTION products in compliance with all these applicable laws and regulations. CSM SOLUTION disclaims any and all liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
11. CSM SOLUTION products and technologies shall not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You shall comply with any applicable export control laws and regulations promulgated and administered by the governments of any countries asserting jurisdiction over the parties or transactions.
12. It is the responsibility of the buyer or distributor of CSM SOLUTION products, or any other party who distributes, disposes of, or otherwise sells or transfers the product to a third party, to notify such third party in advance of the contents and conditions set forth in this document.
13. This document shall not be reprinted, reproduced or duplicated in any form, in whole or in part, without prior written consent of CSM SOLUTION.
14. Please contact a CSM SOLUTION sales office if you have any questions regarding the information contained in this document or CSM SOLUTION products.

(Note1) "CSM SOLUTION product(s)" means any product developed or manufactured by or for CSM SOLUTION.

## Corporate Headquarters

2-4-3 Fukuzumi, Koto-ku, Tokyo 135-0032, Japan

<https://www.cosmo.co.jp/>

## Contact information

For further information on a product, technology, the most up-to-date version of a document, or your nearest sales office, please visit:

<https://www.cosmo.co.jp/support/>

## Trademarks

CSM SOLUTION and the CSM SOLUTION logo are trademarks of CSM SOLUTION CO.,LTD. All trademarks and registered trademarks are the property of their respective owners.

# SAFETY MATTERS

## Definitions of Symbols

A variety of symbols are used in this document and on this product, to prevent the damage to harm and the property to you and other people beforehand by correctly using this product.

This section, Safety Matters, presents these symbols and their meanings. It also presents safety notes to assure that this produce is used safely and correctly.

This product should only be used after fully understanding the material presented in this section.



### **WARNING**

Warning items indicate things that, if not avoided, could lead to death or serious injury.



### **CAUTION**

Caution items indicate things that, if not avoided, could lead injury or damage to the house and household goods, etc.

In addition to the above two symbols, the following are displayed at the same time as required.

**[Important]** These indicate the points which may cause a breakdown or malfunction of equipment by the incorrect setting when setting up this product.

△ indicates WARNING or CAUTION.

Example:



**CAUTION AGAINST ELECTRIC SHOCK**

⊘ indicates PROHIBITION.

Example:



**DISASSEMBLY PROHIBITED**

● indicates a COMPULSORY ACTION.

Example:



**COMPULSORY ACTION**

## **WARNING**

### Handling Related Warnings:



Always check the jumper and switch settings before connecting a power source. An incorrect jumper or switch setting can lead to internal heat generation, rupture, ignition, or damage to this evaluation board itself or any connected equipment.

If, during either the use or storage of this product, any abnormality in the product itself (including abnormal odors, heating, color changes, or changes to the shape of the product) are observed, disconnect the AC adapter immediately.

The incidence of such an abnormality may result in rupture, ignition, or performance deterioration. Therefore, do not use this product in such a situation.

### Installation:



Do not install this product in a location that has a high humidity or where water or other fluids could get on it. This product may be damaged if water or other fluids can get on it.

### Ambient Temperature:



The ambient temperature range for using this product is from 0°C to 60°C.

## CAUTION

### Handling:



This product must be handled carefully. Do not cause a strong impact by dropping it, letting it fall, etc.

Do not touch this product's component pins with bare hands. Doing so may discharge static electricity that damages the Internal circuits. Eliminate static electricity before touching this product.

When connecting or disconnecting cables to or from this product, hold the parts of the cable intended to be grasped (such as the plugs) and avoid putting stress on the cable. Do not pull this product etc. while it is connected with a communications interface cable. Doing so may cause the cable to be disconnected.

When connecting a cable to a connector, do not insert the plug in the reverse direction or upside down. Incorrect insertion may damage this product or connected equipment.

Always check the jumper and switch settings before connecting a power source. An incorrect jumper or switch setting can lead to damage to this product or connected equipment.

Do not handle this product with wet hands. Doing so can lead to failure of the product.

### Transport methods:



When transporting this product, use the product's packing box and cushioning materials and ship it with precision equipment handling. If the products packing is insufficient, it may be damaged during shipping.

If it must be transported by some other method, pack it carefully as precision equipment.

When packing this product, always use the antistatic pouch included with this product.

If some other pouch is used, electrostatic discharge may damage the product.

### Abnormal operation:



If operation of this product becomes abnormal due to interference from external noise etc., apply the following procedure.

1. Turn off the power.
2. Wait 10 or over seconds and then turn the power back on.

### Disposal:



When disposing of this product, be sure to dispose it as industrial waste according to all applicable laws.

# Table of Contents

1. Overview .....	7
1.1 Features.....	8
1.2 Block Configuration.....	9
2. Specifications .....	12
2.1 IMX415 Board-M12 Specifications .....	12
2.2 Outer Appearance .....	13
3. Operating Procedure .....	16
3.1 Assembly (Single Sensor Mode) .....	16
3.2 Assembly (Dual Sensor Mode [Synchronous/Asynchronous]).....	17
3.3 Operation Switch Setting .....	18
3.3.1 Switch Setting (Single Sensor Mode) .....	18
3.3.2 Switch Setting (Dual Sensor Mode [Synchronous] ).....	19
3.3.3 Switch Setting (Dual Sensor Mode [Asynchronous] ).....	20
3.3.4 Switch Setting (RZ/V2H Evaluation Board Kit) .....	21
3.4 Lists of Main Parts .....	22
4. Interface Specifications .....	23
4.1 MIPI CSI-2 Interface .....	23
4.2 Timing signal connector.....	24
4.3 Switches.....	24
Appendix A Attached M12 Lens Specification .....	25
Appendix B Connecting to the RZ/V2N Evaluation Board Kit .....	26

# 1. Overview

This board is an image sensor board (IMX415 Board-M12) for connecting to an evaluation kit for RZ/V2H MPU from Renesas Electronics Corporation. (RZ/V2H evaluation board kit, hereafter V2HEVK). This manual describes the hardware functions of IMX415 Board-M12.

This board is an optional board sold separately from V2HEVK.

It also describes how to connect to the RZ/V2N Evaluation Board Kit. (See Appendix B).

The configuration required to operate the image sensor board is as below.

Table 1.1-1 Required Boards for IMX415 board-M12

Board Name	Overview
RZ/V2H Secure Evaluation Board (CPU board)	<ul style="list-style-type: none"> <li>The RZ/V2H is mounted.</li> <li>Board on which the main functional components for the RZ/V2H are mounted.</li> </ul>
RZ/V2H EVK Expansion Board (EXP board)	<ul style="list-style-type: none"> <li>Connected to J1, J2 and J4 on the RZ/V2H Secure Evaluation Board.</li> <li>Board on which the HDMI, audio, and Pmod interfaces.</li> </ul>
IMX415 Board-M12 (option)	<ul style="list-style-type: none"> <li>Connected to the MIPI CSI-2 connector (CN7, CN8, CN9, CN10) on the RZ/V2H CPU Board.</li> <li>Image sensor board. (on which IMX415 is mounted)</li> </ul>

The following documents have been prepared for IMX415 Board-M12.

Make sure to refer to the latest versions of these documents. For more information, contact a CSM SOLUTION sales representative.

Table 1.1-2 Documents list

Document Type	Document Title	Document No.	Description
Hardware manual	IMX415 Board-M12 for RZ/V2H Evaluation Board Kit Hardware Manual	This document	Hardware specifications of IMX415 Board-M12 for connecting to V2HEVK.

The following documents have been prepared for V2HEVK. Make sure to refer to the latest versions of these documents. For the development environment including software, contact a Renesas Electronics sales representative.

Table 1.1-3 Documents List

Document Type	Document Title	Renesas Website	Description
Hardware manual	RZ/V2H Evaluation Board Kit (Secure type) Hardware Manual	<a href="https://www.renesas.com/us/en/products/microcontrollers-microprocessors/rz-mpus/rzv2h-evk-rzv2h-quad-core-vision-ai-mpu-evaluation-kit">https://www.renesas.com/us/en/products/microcontrollers-microprocessors/rz-mpus/rzv2h-evk-rzv2h-quad-core-vision-ai-mpu-evaluation-kit</a>	Hardware specifications of the V2HEVK
User's Manual: Hardware	RZ/V2H Group User's Manual: Hardware	<a href="https://www.renesas.com/us/en/products/microcontrollers-microprocessors/rz-mpus/rzv2h-quad-core-vision-ai-mpu-drp-ai3-accelerator-and-high-performance-real-time-processor">https://www.renesas.com/us/en/products/microcontrollers-microprocessors/rz-mpus/rzv2h-quad-core-vision-ai-mpu-drp-ai3-accelerator-and-high-performance-real-time-processor</a>	RZ/V2H hardware specifications (pin assignments, memory maps, peripheral specifications, electrical characteristics, and timing charts) and descriptions of operation

## 1.1 Features

IMX415 board-M12 includes the following features.

- IMX415 CMOS Image Sensor : 1 ch
- V2HEVK connector : 1 ch (CN1 [22pin])
- Timing signal connector for image sensor synchronization : INPUT 1ch (CN2 [4pin]) / OUTPUT 1ch (CN3 [4pin])
- Power supply for the IMX415 CMOS image sensor
- Power sequence control for the IMX415 CMOS image sensor

## 1.2 Block Configuration




Figure 1.2-1 IMX415 Board-M12 Block Diagram (Single Sensor Mode)






Figure 1.2-3 IMX415 Board-M12 Block Diagram (Dual Sensor Mode [Asynchronous])

## 2. Specifications

### 2.1 IMX415 Board-M12 Specifications

Table 2.1-1 IMX415 Board-M12 Specifications

Item	Specification
CMOS image sensor	IMX415 (Made by SONY)
Lens Mount	M12 Mount (Lens included in this product.)
Board size	52 × 40 × 1.6 mm (at bare board condition)
V2HEVK Connector	Connector: 22 pins with 0.5-mm pitch For connecting to the V2HEVK via FFC cable.
Timing signal Connector	Connector: 4 pins with 2.5-mm pitch For connecting to the another IMX415 board-M12. (Only in Dual Sensor Mode)
FFC cable (provided)	22 Position, 0.50mm pitch, 100mm

## 2.2 Outer Appearance




Figure 2.2-1 Outer Appearance of V2HEVK (with IMX415 Board-M12 : Single Sensor Mode)




Figure 2.2-2 Outer Appearance of V2HEVK (with IMX415 Board-M12 : Dual Sensor Mode [Synchronous])




Figure 2.2-3 Outer Appearance of V2HEVK (with IMX415 Board-M12 : Dual Sensor Mode [Asynchronous])



Figure 2.2-4 IMX415 Board-M12 (IMX415 sensor side)




Figure 2.2-5 IMX415 Board-M12 (V2HEVK connector side)

## 3. Operating Procedure

### 3.1 Assembly (Single Sensor Mode)

The V2HEVK and IMX415 board-M12 are connected with FFC.

FFC is connected with following procedure:

1. Open the FFC locking cover, align the FFC contacts to the bottom, and close the cover until it locks.

The cover is fragile, so handle with care.




Figure 3.1-1 Connect FFC to IMX415 Board-M12.

2. Connect the FFC to V2HEVK (CPU Board).

The cover is fragile, so handle with care.




Figure 3.1-2 Connect FFC to RZ/V2H Secure Evaluation Board.

### 3.2 Assembly (Dual Sensor Mode [Synchronous/Asynchronous])

Connect the two IMX415 board-M12 together with the on-board connector.

Be sure to connect this when using the Dual Sensor Mode [Synchronous]. If you are using the Dual Sensor Mode [Asynchronous], you do not need to connect it (there is no problem if you connect it).

1. Connect CN3 of the first unit (master setting) to CN2 of the second unit (slave setting).




Figure 3.2-1 Connect the on-board connectors of the IMX415 board-M12.

2. Connect the FFC in the same way as in single sensor mode.

### 3.3 Operation Switch Setting

The table below lists the settings of the slide switch on the IMX415 Board-M12 and RZ/V2H Evaluation Board Kit.

#### 3.3.1 Switch Setting (Single Sensor Mode)

Table 3.3-1 Switch settings in Single Sensor Mode

No	Part Symbol	Setting
1	SW1	1:OFF 2:OFF
2	SW2	ON (Master Mode)
3	SW3	ON (Master Mode)




Figure 3.3-1 Switch Setting in Single Sensor Mode

### 3.3.2 Switch Setting (Dual Sensor Mode [Synchronous])

Table 3.3-2 Switch settings in Dual Sensor Mode [Synchronous]

No	Part Symbol	Setting
First Unit (Master)		
1	SW1	1:OFF 2:OFF
2	SW2	ON (Master Mode)
3	SW3	ON (Master Mode)
Second Unit (Slave)		
1	SW1	1:OFF 2:OFF
2	SW2	OFF (Slave Mode)
3	SW3	OFF (Slave Mode)




Figure 3.3-2 Switch Setting in Dual Sensor Mode [Synchronous]

### 3.3.3 Switch Setting (Dual Sensor Mode [Asynchronous] )

Table 3.3-3 Switch settings in Dual Sensor Mode [Asynchronous]

No	Part Symbol	Setting
First Unit (Master)		
1	SW1	1:OFF 2:OFF
2	SW2	ON (Master Mode)
3	SW3	ON (Master Mode)
Second Unit (Master)		
1	SW1	1:OFF 2:OFF
2	SW2	ON (Master Mode)
3	SW3	ON (Master Mode)




Figure 3.3-3 Switch Setting in Dual Sensor Mode [Asynchronous]

### 3.3.4 Switch Setting (RZ/V2H Evaluation Board Kit)

Table 3.3-4 Switch settings in RZ/V2H Evaluation Board Kit

No	Part Symbol	Setting
1	JSW1	1-2: MIPI CSI-2 Camera Interface Voltage: 1.8V
2	DSW3	ALL OFF I2C signal Pull-Up OFF for MIPI CSI-2[Ch0-Ch3].

\* detailed functions, please refer to the RZ/V2H Evaluation Board Kit Hardware Manual.




Figure 3.3-4 Switch Setting in RZ/V2H Evaluation Board Kit

### 3.4 Lists of Main Parts

**Table 3.4-1** list the main parts of the IMX415 Board-M12.

**Table 3.4-1** IMX415 Board-M12 Parts List

No.	Quantity	Part Symbol	Part Name	Manufacturer
1	1	U1	IMX415-AAQR	Sony
2	2	U2, U3	5PB1102CMGI8	Renesas Electronics
3	1	U5	S-77101A11-T8T1U4	ABLIC
4	2	U6, U7	ISL8002IRZ-T7A	Renesas Electronics
5	1	U8	ISL80505IRAJZ	Renesas Electronics

## 4. Interface Specifications

This section describes the interface specifications of the IMX415 Board-M12.

### 4.1 MIPI CSI-2 Interface

#### Caution

It is different from the Raspberry Pi camera interface. When connecting the Raspberry Pi, carefully confirm each signal connection. Incorrect connections may damage the board or module.

Table 4.1-1 V2HEVK connector (CN1)

Pin No.	Connection	Pin No.	Connection
1	GND	12	CAM_D2_P
2	CAM_D0_N	13	GND
3	CAM_D0_P	14	CAM_D3_N
4	GND	15	CAM_D3_P
5	CAM_D1_N	16	GND
6	CAM_D1_P	17	POW_ENB
7	GND	18	XCLR
8	CAM_CK_N	19	GND
9	CAM_CK_P	20	SCL
10	GND	21	SDA
11	CAM_D2_N	22	+3.3V input

## 4.2 Timing signal connector

The IMX415 board-M12 has a timing sync signal connector for dual sensor mode. Input (CN2) and Output (CN3) .

Table 4.2-1 Timing Signal Input Connector (CN2)

Pin No.	Connection
1	INCK_I
2	XVS_I
3	XHS_I
4	GND

Table 4.2-2 Timing Signal Output Connector (CN3)

Pin No.	Connection
1	INCK_O
2	XVS_O
3	XHS_O
4	GND

## 4.3 Switches

The IMX415 Board-M12 has three switches. Table 4.3-1 list the functions of the respective switches.

Table 4.3-1 IMX415 Board-M12 Switch

Switch	Usage																				
SW1	IMX415 I2C Slave Address																				
	<table border="1"> <thead> <tr> <th>1</th> <th>2</th> <th>Write</th> <th>Read</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>OFF</td> <td>34H</td> <td>35H</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>20H</td> <td>21H</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>6CH</td> <td>6DH</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>6EH</td> <td>6FH</td> </tr> </tbody> </table>	1	2	Write	Read	OFF	OFF	34H	35H	OFF	ON	20H	21H	ON	OFF	6CH	6DH	ON	ON	6EH	6FH
1	2	Write	Read																		
OFF	OFF	34H	35H																		
OFF	ON	20H	21H																		
ON	OFF	6CH	6DH																		
ON	ON	6EH	6FH																		
SW2	Clock Select																				
	<table border="1"> <tbody> <tr> <td>OFF</td> <td>External clock use (Slave Mode)</td> </tr> <tr> <td>ON</td> <td>Internal clock use (Master Mode)</td> </tr> </tbody> </table>	OFF	External clock use (Slave Mode)	ON	Internal clock use (Master Mode)																
OFF	External clock use (Slave Mode)																				
ON	Internal clock use (Master Mode)																				
SW3	Sync Signal (VS/HS) Select																				
	<table border="1"> <tbody> <tr> <td>OFF</td> <td>External signal use (Slave Mode)</td> </tr> <tr> <td>ON</td> <td>Internal signal use (Master Mode)</td> </tr> </tbody> </table>	OFF	External signal use (Slave Mode)	ON	Internal signal use (Master Mode)																
OFF	External signal use (Slave Mode)																				
ON	Internal signal use (Master Mode)																				

## Appendix A Attached M12 Lens Specification


The Optical Specifications of the M12 Lens mounted on the IMX415 board-M12 are shown below.

### Optical Specifications

Item	Detail
Product Number	DSL401A-660-F2.8
Maker	Sunex
Nominal Imager Format	Up to 1/2"
Imager Resolution	Up to 16MP
Focal Length	2.8 mm
Relative Aperture (F/#)	F/2.8
Image Circle	8.0 mm
Field of View	73° at 4.6mm image circle 92° at 6.2mm image circle 108° at 7.8mm image circle
Total Track Length	24 mm
Distortion	+29% from F- $\theta$ , <13% rectilinear
Chief Ray Angle	14° at 8.0mm image circle, linear
IR cut-off filter	Optional 660 nm IR cutoff filter

The focal length can be adjusted by changing the screw-in of the lens.

The focal length has not been adjusted and the lenses have not been glued in place when shipped. Please adjust as necessary.



## Appendix B Connecting to the RZ/V2N Evaluation Board Kit


The following documents have been prepared for V2NEVK. Make sure to refer to the latest versions of these documents. For the development environment including software, contact a Renesas Electronics sales representative.

### Documents List


Document Type	Document Title	Renesas Website	Description
Hardware manual	RZ/V2N Evaluation Board Kit (Secure Type) User's Manual	<a href="https://www.renesas.com/en/products/microcontrollers-microprocessors/rz-mpus/rzv2n-evk-rzv2n-quad-core-vision-ai-mpu-evaluation-kit">https://www.renesas.com/en/products/microcontrollers-microprocessors/rz-mpus/rzv2n-evk-rzv2n-quad-core-vision-ai-mpu-evaluation-kit</a>	Hardware specifications of the V2NEVK
User's Manual: Hardware	RZ/V2N Group User's Manual: Hardware	<a href="https://www.renesas.com/en/products/microcontrollers-microprocessors/rz-mpus/rzv2n-15tops-quad-core-vision-ai-mpu-2-camera-connection-and-excellent-power-efficiency">https://www.renesas.com/en/products/microcontrollers-microprocessors/rz-mpus/rzv2n-15tops-quad-core-vision-ai-mpu-2-camera-connection-and-excellent-power-efficiency</a>	RZ/V2N hardware specifications (pin assignments, memory maps, peripheral specifications, electrical characteristics, and timing charts) and descriptions of operation

The following explains how to connect to the RZ/V2N Evaluation Board Kit.

## Outer Appearance



**Figure. 1** Outer Appearance of V2NEVK (with IMX415 Board-M12 : Single Sensor Mode)




**Figure. 2** Outer Appearance of V2NEVK (with IMX415 Board-M12 : Dual Sensor Mode)

## Switch Setting (RZ/V2N Evaluation Board Kit)

**Table. 1** Switch settings in RZ/V2N Evaluation Board Kit

No	Part Symbol	Setting
1	JSW1	1-2: MIPI CSI-2 Camera Interface Voltage: 1.8V
2	DSW3	ALL OFF I2C signal Pull-Up OFF for MIPI CSI-2[Ch0-Ch1].

\* detailed functions, please refer to the RZ/V2N Evaluation Board Kit Hardware Manual.



**Figure. 3** Switch Setting in RZ/V2N Evaluation Board Kit

REVISION HISTORY	IMX415 Board-M12 for RZ/V2H Evaluation Board Kit Hardware Manual
------------------	---

Rev.	Date	Description	
		Page	Summary
1.00	May 12, 2025	—	First edition issued

---

IMX415 Board-M12 for RZ/V2H Evaluation Board Kit  
Hardware Manual

Publication Date: Rev.1.00 May 12, 2025

Published by: CSM SOLUTION CO., LTD.

---